




MAJOR

Pleasure Toy

Say hello to your new obsession.

Major brings waterproof power, multi-rotation, digging and thrusting that hits every mark. Smooth silicone, rechargeable battery and majorly good vibes. It's giving satisfaction, it's giving confidence - **it's giving Major.**



- **Material:** Safe silicone (soft and comfortable)
- **Waterproof rating:** IPX6 - Safe for use in the shower, do NOT fully submerged.
- **Vibration modes:** 10 exciting patterns + Thrusting, Digging & Rotation
- **Charging time:** 120 - 150 minutes
- **Usage time:** 60 minutes use
- **Product size:** 104 x 38 x 182 mm

Safety Guidelines

- For hygiene, do not share your toy.
- Stop using it immediately if you feel discomfort.
- Inspect the toy before each use. Do not use it if the head is damaged or rough.
- Keep out of reach of children.

Usage Tips

- Always use a water-based or body-safe lubricant for a smooth, comfortable experience.
(We recommend Moments Lubricants for the best results!)
- Always charge before first use.

Cleaning & Maintenance

Clean thoroughly before and after with warm water or medicinal alcohol (warm water is recommended). Air dry naturally, avoid direct sunlight.

Store in a dust-free place away from heat and sunlight.


Dispose of your toy responsibly according to local regulations. For guidance, contact your local waste disposal office.


✦ How to Use

Turn ON/OFF:


Press and hold  button for 1.5 seconds.


Switch A Head Frequency Settings:

Quickly press  button to switch A head vibration, thrusting and digging frequency cycle.

Double-click  to pause A head vibration, thrusting and digging function.

Switch B Head Frequency Settings:

Quickly press  button to switch B head vibration and rotation frequency cycle.


Double-click the  button to pause B head vibration and rotation function.

Flashing Light=Charging

Solid Light=Fully Charged

Low Battery Reminder:

The light flashes quickly until it's turned off.



✦ Charging Instructions

- Ensure the charging outlet is dry and free of lubricants.
- Connect the provided DC charging plug.
- Charge for 80-100 minutes.
- A blinking white light indicates charging; a solid white light means fully charged.
- Unplug before use.
- Full charge lasts 90-120 minutes.